


## Setting the Date and Time Ignite®

1. Go to **Tools** in the gray tool bar and select **Configuration**.





2. Find the “**Change the Date and Time**” button:

- a. If the button is on the **Configuration Summary** page, select it and update the time.





- b. If it is **NOT** there, select “**Get Sign Controller Status**.” A new screen will open. If the button to change the date and time is there, select it and update the time.



- c. If the button is **NOT** there, go to **Sign Controller Set-up** on the left side of the page. A new screen will open, click the ‘**Connect**’ button.\* In the new screen, select the ‘**Change**’ button next to the Date and Time information.



- i. Once the time is updated, select the **Update Settings** button at the bottom of the screen to update the new settings.



3. Once the time is corrected, wait **2 minutes** for the sign to update (**the sign will go blank**), and verify that the time is correct.

\*If the sign asks for a Tech Support Password, or you have further questions, please contact Time-O-Matic's® Tech Support at 866-637-2645.

RightNow Answer #146.